

cleaning & care instructions

cleaning & care

tabi CeramicSteel markerboards

Before first use:

- If applicable, remove the protective film from the board.
- Moisten a clean cloth with high-quality whiteboard cleaner and wipe the board clean.
- Wipe the surface again, using a clean, dry cloth.

Daily cleaning:

- Erase all content on the board.
- Moisten a clean cloth with warm water and wipe the board clean.
- Wipe the surface again using a clean, dry cloth.

Weekly cleaning:

- Moisten a clean cloth with high-quality whiteboard cleaner and wipe the board clean
- Wipe the surface again, using a clean, dry cloth.
- Surfaces used moderately should be cleaned two or three times per week. Surfaces used more frequently may require daily cleaning.

Note: Using a non-appropriate cleaner may result in poor dry erasability due to the build up of residue from the cleaner on the surface.

tabi CeramicSteel chalkboards

Before first use:

- If applicable, remove the protective film from the board.
- Apply chalk to the entire surface using the long side of a chalk stick
- Erase the chalk with a latex or felt eraser
- Moisten a clean cloth with warm water and wipe the board clean.
- Rinse again with clean water and wipe the surface using a window stripper/squeegee
- Allow to dry completely before using

Daily cleaning:

- Erase content on board with a latex or felt eraser.
- Moisten a clean cloth with warm water and wipe the board clean.
- Rinse again with clean water and wipe the surface using a window stripper/squeegee
- · Allow to dry completely before using
- Boards used moderately should be cleaned two or three times per week. Boards used more frequently may require daily cleaning.

Note: Remember to keep the erasers dry, and clean them regularly for best performance.

tabi glassboards

- Moisten a clean cloth, soft paper towel or clean synthetic sponge with a mild detergent or glass cleaner and wipe the board in a circular motion.
- Wipe surface dry with a clean cloth.

Note:

- Do not clean the glass when it's hot or in direct sunlight.
- Do not allow water or cleaning residue to remain on the glass surface.
- Do not use abrasive cleaning solutions or materials for maintenance cleaning
- Do not allow metal parts of cleaning equipment to contact the glass.
- Do not use razor blades on glass surfaces

tabi Textiles

- Wipe with a damp cloth using soap and water or use proprietary upholstery shampoo.
- For deeper cleaning, use alcohol spray or wipes. Bleach can be used by following the guidelines below.
- Anti-bacterial sprays and wipes can be used to wipe down the fabric to disinfect.

General commercial disinfection

- Use a household bleach (containing approx.
 4.5 oz. per 100 oz. of sodium hypochlorite),
 which should then be used in a 1:10 dilution
- Follow the instructions of the brand you're using.
- Measure out the required dose in relation to the quantity of water, soak a white or lightly colored cloth in the solution, squeeze out any excess liquid and gently wipe the fabric before leaving to dry.

Note: Fabrics have been developed to withstand regular cleaning maintenance and disinfection. Please follow the manufacturer instructions on cleaning and disinfection agents. We recommend spot-testing on an inconspicuous part of the material first. Fabric samples are available for testing by contacting: info@tabiforteams.com.

Doc # 100134 | Rev A Doc # 100134 | Rev A

1 888 325 6351 info@tabiforteams.com tabiforteams.com ©2020 PolyVision Corporation. All rights reserved. Trademarks used herein are the trademarks of PolyVision Corporation or their respective owner. PolyVision Corporation reserves the right to make changes in product design, construction or detail, and to discontinue any product or material without notice. Tabi products are manufactured by PolyVision Corporation.

cleaning and care instructions August 2020 Doc # 100134 | Rev A

