



90.25"



Drill inside each cross

Drill inside each cross



Drill inside each cross

Gap between panels

WARNING

CRUSH HAZARD
Panels are heavy. Falling or dropped panels can cause serious injury. Follow all safety instructions.

SAFETY INSTRUCTIONS

- Only install with trained professionals.
- Use all safety instructions on installation template before beginning installation.
- Use proper safety procedures to load and tie off load.
- Use all necessary hardware for use on drywall only.
- Use all necessary safety and in required positions per instructions.
- Contact Tabi Support for more information if you have questions.

NOTICE
Building owner or installer must be responsible to verify the installation is compliant to local codes and regulations. Manufacturer is not liable for installation on surfaces other than drywall.

Assembly Directions

00 Tooling

The following tools will be needed during the installation of the work wall.

01 Drilling templates

The drilling templates function as a mock-up of the panels. Please hang the drilling templates level and in the right position since they are an exact replication of each panel and gap. The drilling templates will provide you with complete references for the further installation.

A Position drilling templates.

Tap the paper drilling templates of the panels to the wall (A).

B Mark holes.

Using an awl for either sharp object, punch a hole through the template and into the wall surface to clearly mark each location. When all marking locations are marked clearly, remove templates from the wall.

C Assemble.

Once drilled anchor of each location marked in the previous step (C1), assemble recording hardware by screwing in one spacer (C2), one dual lock hook (C3) and one screw (C4) to each drywall anchor.

02 Leveling of dual lock hooks

It is critical for the aesthetics of the complete installation that all dual lock hooks are leveled in the same Z-Plane. Find the most protruding point of the wall to start from.

A Set up laser level.

Project a laser plane parallel to the wall surface and as close to the wall as possible (A1). Using a tape measure or similar measuring tool, determine which dual lock hook location protrudes from the wall surface the most. Make a mark on the wall to indicate which location produces the most.

Note: It is important to make sure the laser plane is as parallel to the wall as possible!

B Level the dual lock hooks.

A wall spacer must be behind each dual lock location, and only one wall spacer is provided per dual lock location. Measure the offset from each dual lock location to the laser level plane (B1). If the offset is larger than the dual lock location marked in the previous step, lower the screw (B2) and insert the appropriate number of provided shim spacers to match the offset of the most protruding location (B3).

03 Mount the panel.

The panel should be positioned as accurate as possible.

A Add reference.

Add reference to the panel and the wall to align the corner of the dual lock hook and the panel (A1).

B Position and level the panel.

When the panel is level (B1) and the corner position is still off, take with the aid of a hand from the panel in each direction. This again takes care of the dual lock location (B2). Finally, lower wall spacer (B3) to match the dual lock location. Double safety instructions at the top of template. Use at least two people to lift and install panels. One person must hold the panel and level with a second person sets each dual lock location as marked on each panel.


C Need to make adjustments?

If panels are not positioned correctly, it is possible to remove the panel by gently pulling the edge of the panel with both hands diagonally to each dual lock location (starting in the corner) and push it away from the wall (C1). After one dual lock hook has been popped loose, move on to the next one until the panel is free. Dual lock hooks can be re-used and disconnected several times if required.

42.25"


42.25"

90.25"




Drill inside each cross

Drill inside each cross



Drill inside each cross



If you have problem, question, or request, call your local dealer, or Tabi Support at: 1 888 325 6351 or 1 678 542 3078 Mon - Fri: 8:00 AM - 5:00 PM info@tabiforteam.com Or visit our website: tabiforteam.com

